



Skyline Wall Coping Installation Guide



Need any assistance? Call us today
0330 223 1731

Skyline Line Coping



- Using recommended fixing screws, fix wall coping strap to structure at maximum 1.5 metre centre's or as recommended based on wind uplift calculations
- Note that waterproofing membrane by other is not shown. Where fixing penetrate through use bead of silicone to seal e.g Dow Corning silicone

Skyline Line Coping



- Using Locate wall coping over half of the wall bracket at joint and rotate down



- Apply pressure to the coping to clip it into place, compressing the EPDM seal (shown)
- Repeat on next length or fitting & leave a 4mm gap for expansion